



www.meta.com.tw

### · 安装支架




The figure illustrates the proposed algorithm for determining if a sequence of operations (T, X, R) can be performed on a stack to achieve a target sequence. The left side shows a sequence of operations (T, X, R) on a stack. The right side shows a sequence of operations (T, R, X) on a stack. The left side is marked with 'X' and the right side with '✓'.

D: 安全距离 (mm) -- 检测区域表面与机器的危险部分之间所需的最小距离

1

## 2、避免反射面与强光的干扰



2

本产品默认为状态一，如需更改请自行按上述方式设定，设定动作皆须在接通电源后五秒内完成。

A diagram of a cell with several organelles labeled with circled numbers. Label 1 points to a large, oval-shaped nucleus. Label 2 points to a small, circular mitochondrion. Label 3 points to a small, oval-shaped vacuole. Label 4 points to a small, rectangular chloroplast. Label 5 points to a small, circular lysosome.

① 棕色线	+24V DC
② 黑色线	常开
③ 蓝色线	地线
④ 白色线	常闭
⑤ 红色线	选择重置模式

3

图一

图二

4

不亮——损坏或有故障

5

技术规格	光轴数	8 / 16 / 24 / 32 / 40 / 48 / 56 / 64	
	光轴距	15mm / 20mm / 25mm / 30mm	
	保护幅宽	光轴距 × ( 光轴数 - 1 )	
	最小检出物体	20mm / 25mm / 30mm / 35mm	
	电源电压	24VDC	
	功耗	< 8W	
	反应时间	( 0.5 × 光轴数 + 5 ) ms	
	结构	外壳: 铝合金 ; 端盖: ABS工程塑料 ; 支架: 冷轧钢板	
	检测距离	0.5 ~ 5m / 10m	
验证	符合CE LVD 要求 ; 无安全分类 ( 请勿使用于冲剪类之危险机械 )		
输出	输出形式	同时输出 PNP NO/NC 或 NPN NO/NC	
	输出电流	200mA	
使用环境	温度	-10 ~ +55℃ ( 注意不可结露、结冰 )	
	湿度	15 ~ 85%	
	抗光性	太阳光: 10000LX    白炽灯: 3000LX	
存储	抗震动	频率: 10 ~ 55Hz    振幅: 0.75mm	
	温度	-25 ~ +70℃ ( 注意不可结露、不可结冰 )	
指示灯	发射器	黄色	发射器自检
		绿色	正常运作
		黄色	接收器自检
	接收器	绿色	正常运作
		红色闪烁	受遮蔽 ( 使用者可依本身需求设定三种不同的闪烁方式 )

6